4	5	6	7	8	9	-/--	0	
TOSHIBA	JVC	LG GOLDSTAR	MITSUBISHI	SHARP	PANASONIC	HITACHI	NEC/ SHIVAKI	SANYO

ut (Turn on the TV,wait the image come out)

key[SET] and [POWER] release it.

number refers to the code turns off, the setting is

in function. If it does not from step 1-2 or try other

top setting , please press

ch

V, Wait the

2.Press and hold the key [SET] and [POWER] until the LED is lit, release it



try again and

4.When the TV volume changes, press [SET] key to save and exit.

he main

6. If it can work , the set is ok. If it does not work, please repeat from step 1-4

ch

to theTV. Press and hold the key [SET],about 5 LED is lit. It will search automatically.

ume changes, please release the key. It will save the

matic search process, only If the volume of the TV ress the key[SET] to save the setting. If other things such as channel change, please ignore It.]

ain function. If It does not work, please repeat from

h

② Press and hold [MUTE] firstly, then press and hold [CH UP], about 5 seconds indicator will be lit. Release two keys

③ Press the key [CH UP] or [CH DOWN], each time you press it will search once. When the channel changes, please release the key and press[MUTE] to save the code.

④ Skip step3, If long press the key[CH UP]/[CH DOWN] for more than 1 second, it will search fast. When the channel changes, please release the key. Press[CH DOWN]/[CH UP] to adjust the code. If the channel changed again, please press[MUTE] to save the code.

D: NOTES

- ONLY YOUR TV HAVE RECEIVING FUNCTION OR RECEIVING EQUIPMENT THEN CAN USE THIS REMOTE.
- IF IMPROPER OPERATION, THE REMOTE MAY DIED so NOW YOU SHOULD TAKE OUT THE BATTERY AND WAIT 20 MINUTES THEN PUTIN THE BATTERY AND RE-SET

E: SERVICE

If you have troubles in using the remote control so please contact us. We will try our best to serve you. Please don' t open the controller by yourself. We will not take the responsibility if you open it by yourself.

RT9661 TV CODE LIST

BRAND	CODE
A·IWA	814,827,884
A·KAI	886,157,885,809,176,053,782 787,795,840,845,849,850,854 863,865,887,888,889,059,006 890,891,073,883
A·KIRA	886,786,746,447,704,053,384,537, 539,519,440,807,892,893,894,044
A·VEST	176,807
B·BK	134
B·EKO	895,896,897,040,374
B·ENQ	841,846
C·HANGHONG	028,130,131,136,139,141,146,151,156 161,166,171,176,181,186,196,201,285 315,323,331,340,341,346,351,361,365 366,371,376,381,386,390,396,401,406 411,415,416,421,431,432,436,440,441 446,451,456,457,461,466,474,476,481 482,486,491,498,502,658,663,668,679 683,688,729,745,781,786,791,852,858
C·ONROWA	063,068,178,353,468,473,514, 537,542,547,552,562,740
C·YBEX	752
D·AEWOO	808,813,819
D·RE	855,927,924
E·RISSON	898,746,807,764,157,440,814,148,033
E·LENBERG	248,258,265,807
F·UNAI	412,899,900,248,807
G·ENERAL	924,927,855
G·OLDSTAR	776,530,797,798,803,818,830,861,862 901
G·RUNDIG	843,777,778,783,788,793,Video(874)
H·AIER	524,001,033,059,158,190,195,205 214,219,524,529,534,682,684,687 694,715,720,739,756,761,774,807 812,825,832
H·I-VISION	152
H·ITACHI	019,037,076,103,108,113,116,149,496 501,506,526,531,536,541,545,546,551 556,561,566,571,749,811,816,821,826 511,516,521
H·ORIZONT	530,901,902,903,775,789,794,796,799 801,823,837,857,859.

BRAND	CODE
H·ISENSE	133,003,016,022,024,034,035,043,044 132,163,168,173,185,204,209,229,276 281,291,296,301,338,343,348,448,453 458,463,511,516,519,535,538,548,553 558,559,563,564,567,568,569,572,573 574,578,579,582,583,584,587,589,592 602,607,612,622,627,632,642,647,672 677,699,700,704,705,706,710,711,716 766,779,856
H·YRUNDAI	746,133,447
J·AV	066
J·INXING (S·VA)	010,020,153,164,169,213,218,223,228 316,373,429,492,493,497,507,521,580 590,635,640,645,650,655,660,676,737 744
J·VC	757,762,767,772,802
K·ONKA	879,033,006,012,014,038,062,072,074 077,115,120,124,125,144,248,253,258 263,268,273,278,283,288,293,298,303 308,313,318,352,362,367,372,377,387 392,394,399,404,408,424,479,484,489 494,499,504,605,610,641,646,651,656 686,701,707,721,726,731,800,805,810 878
L·G	056,096,447,520,525,530,576, 586,591,596,601,771,776
L·OEWE	922
M·ITSUBISHI	760,829,831,834,835,860
N·EC	876
O·RION	904,905,923,807
P·ANAROMA	045
P·ANASONIC	906,053,078,114,133,243,319,324 329,334,339,344,349,354,359,364 434,439,444,550,696,817,822,864 869
P·ANDA	002,042,047,052,107,140,152,154 159,233,238,321,378,383,414,452 462,467,472,477,487,509,555,565 570,630,708.
P·EONY	017,082,135,189,310,488,512,517 522,665,666,671,691,742.
P·HILIPS	015,040,064,901,069,070,075,080 085,090,095,100,105,110,230,240 245,754,759,764
P·OLAR	020,447
P·ROWEST	926
P·RIMA	013,018,023,027,049,067,089,112,117 122,134,145,157,192,200,211,235,237 250,260,272,307,328,332,357,374,382 407,449,454,459,464,469,661,693,698 703,722.

BRAND	CODE
Q·INGHUATONGFANG	046,051,118,593,719,734,743
R·EKORD	133,907,908,909,910
R·OLSEN	176,432,157,883,775,789,794,796,799,801, 823,837,857,859,911,912
R·OWA	092,102,183,188,193,199,358,455,527, 581,690,695
R·UBIN	897,902,779,040
S·AMSUNG	877,007,009,137,142,147,194,306,360, 363,368,385,419,478,483,609,614,619, 624,629,634,670,675,680,681,685,755
S·ANAM	872,883
S·ANYO	011,058,101,123,143,148,206,333,503, 508,513,518,523,528,533,713,735,815, 820
S·ANSUI	748
S·HIVAKI	759,893,447,482

BRAND	CODE
S·KYWORTH	000,005,026,031,036,045,050,054,055, 060,065,079,086,091,111,121,129,138, 150,155,160,162,165,167,170,172,175, 177,180,182,187,197,202,207,212,217, 222,225,227,232,242,247,252,257,262, 267,277,282,287,292,297,302,312,317, 322,326,327,337,342,347,369,379,384, 389,470,490,515,532,539,540,544,549, 557,560,575,577,585,588,595,597,600, 603,608,613,617,618,623,628,633,637, 638,643,648,652,653,657,662,664,667, 669,673,674,678,702,709,712,717,725, 727,730,746,751,765,769,770,780,785, 790,839,844.
S·ITRONIKC	053
S·NOWA	875,880,882,928
S·OKOL	804,809
S·TRONG	833,842,847,851,866,868,
S·ONY	913,088,093,098,106,109,234,239,244, 249,254,259,264,269,274,279,284,289, 294,299,304,309,314,428,836
S·VA	025,041,198,203,208,554,738
S·HARP	917,104,126,388,393,398,403,408,413, 418,423,758,763,768,773
S·UPRA	748,794,133
T·CL	447,021,039,048,081,087,094,099,255, 265,270,275,280,290,295,300,305,320, 325,330,335,345,350,355,370,375,380, 395,397,400,402,405,410,412,417,420, 422,425,427,430,433,435,437,438,442, 443,445,450,460,465,475,480,485,495, 500,505,510,606,611,615,616,620,621, 625,626,631,636,639,644,649,654,659, 718,723,724,728,733,753,784,848.
T·HOMSON	853,914,915,916,792,824,828,838,867
T·OSHIBA	081,191,216,221,226,231,236,241,246, 251,256,261,266,286,311,336,356,391, 426,471,806
V·ESTEL	919,918,920,015
V·ITYAS	921,530,015
X·IHU	008,029,030,071,084,174,179,184,741
X.VISION	873
H·R13	882
O·THERS	004,032,057,073,083,097,119,127,128, 210,215,220,224,271,543,594,598,599, 604,689,692,697,714,732,736,747,750

Environmental Information

This product may contain substances that can be hazardous to the environment or to human health if it is not disposed of properly. We therefore provide you with the following information to prevent releases of these substances and to improve the use of natural resources. Electrical and electronic equipments should never be disposed of in the usual municipal waste but must be separately collected for their proper treatment. The crossed-out bin symbol, placed on the product and in this page, remind you of the need to dispose of properly the product at the end of its life. In this way it is possible to prevent that a not specific treatment of the substances contained in these products, or their improper use, or improper use of their parts may be hazardous to the environment or to human health. Further more this helps to recover, recycle and reuse many of the materials used in these products. For this purpose the electrical and electronic equipment producers and distributors set up proper collection and treatment systems for these products. At the end of life your product contact your distributor to have information on the collection arrangements. When buying this product your distributor will also inform you of the opportunity to make free with another device at the end of life condition that is of equivalent type and has fulfilled the same functions of the product purchased, or if the size is not larger than 25 cm, WAEE can be made without obligation to purchase the product equivalent. A disposal of the product different from what described above will be liable to the penalties prescribed by the national provisions in the country where the product is disposed of. We also recommend you to adopt more measures for environment protection: recycling of the internal and external packaging of the product and disposing properly used batteries (if contained in the product). With your help it is possible to reduce the amount of natural resources used to produce electrical and electronic equipments, to minimize the use of landfills for the disposal of the products and to improve the quality of life by preventing that potentially hazardous substances are released in the environment.

EC REP Furture Telecom Plus Sl
Calle Purísima Concepcion 7 1der,
28982 Parla, Madrid.
Info.futuretelecomplus@gmail.com

Manufacturer: HK Uslink Trading Limited
Address: FLAT/RM A133 Blk 01 15/F Wah Sang Building Nos. 14-18 Wong Chukyeung Street Shatin
E-mail: se:vices@unicostar.com

4	5	6	7	8	9	-/--	0	
TOSHIBA	JVC	LG GOLDSTAR	MITSUBISHI	SHARP	PANASONIC	HITACHI	NEC/ SHIVAKI	SANYO

ón manual (Encienda el televisor, y espere a que salga la imagen)

la tecla [SET] y [POWER] ncienda, y luego deje de

úmeros de código se refiere uando la luz LED se apaga, ará completado.

incipal. Si no funciona, repita ruebe con otras formas de

la configuración, presione un tiempo.



anual

visor, espere gen.

2.Presione y mantenga presionadas las teclas [SET] y [POWER] hasta que el LED se encienda y luego deje de presionarlo.



OL+] varias

4. Cuando cambie el volumen de la TV, presione la tecla [SET] para guardar y salir.

ón principal.

6. Si funciona, la configuración se habrá realizado correctamente. Si no funciona, repita desde el paso 1 - 4

mática

r con el mando a distancia. Mantenga presionada la 5 segundos hasta que se encienda el indicador LED. rá automáticamente.

l volumen de la TV, suelte la tecla y se guardará la

eso de búsqueda automática, solo si cambia el evisor, presione la tecla [SET] para guardar la ocurren cosas como cambios de canal, ignórelo.]

principal. Si no funciona, repita desde el paso 1.

pida

② Presione y mantenga presionado [MUTE] y luego presione y mantenga presionado [CH UP], se iluminará el indicador durante aproximadamente 5 segundos Deje de pulsar las teclas.

③ Presione la tecla [CH UP] o [CH DOWN], cada vez que presione se buscará una vez. Cuando el canal cambie, suelte la tecla y presione [MUTE] para guardar el código.

④ Omita el paso 3, si mantiene pulsada la tecla [CH UP] / [CH DOWN] durante más de 1 segundo, buscará rápidamente. Cuando cambie el canal, suelte la tecla. Presione [CH DOWN] / [CH UP] para ajustar el código. Si el canal cambia nuevamente, presione [MUTE] para guardar el código.

D: NOTAS

- SÓLO PODRÁ UTILIZAR ESTE MANDO A DISTANCIA SI SU TV TIENE FUNCIÓN DE RECEPCIÓN O EQUIPO DE RECEPCIÓN.
- SI NO FUNCIONA CORRECTO, LAS PILAS DEL MANDO A DISTANCIA PUEDEN ESTAR AGOTADAS. RETIRE LAS PILAS Y ESPERE 20 MINUTOS ANTES DE VOLVER A COLOCARLAS.

E: SERVICIO

Si tiene problemas para usar el mando a distancia, póngase en contacto con nosotros. Haremos todo lo posible para servirle. No abra el mando usted mismo. No nos haremos responsables si lo desmonta usted mismo.

RT9661 LISTA DE CÓDIGOS DE TV

MARCA	CÓDIGO
A·IWA	814,827,884
A·KAI	886,157,885,809,176,053,782 787,795,840,845,849,850,854 863,865,887,888,889,059,006 890,891,073,883
A·KIRA	886,786,746,447,704,053,384,537, 539,519,440,807,892,893,894,044
A·VEST	176,807
B·BK	134
B·EKO	895,896,897,040,374
B·ENQ	841,846
C·HANGHONG	028,130,131,136,139,141,146,151,156 161,166,171,176,181,186,196,201,285 315,323,331,340,341,346,351,361,365 366,371,376,381,386,390,396,401,406 411,415,416,421,431,432,436,440,441 446,451,456,457,461,466,474,476,481 482,486,491,498,502,658,663,668,679 683,688,729,745,781,786,791,852,858
C·ONROWA	063,068,178,353,468,473,514, 537,542,547,552,562,740
C·YBEX	752
D·AEWOO	808,813,819
D·RE	855,927,924
E·RISSON	898,746,807,764,157,440,814,148,033
E·LENBERG	248,258,265,807
F·UNAI	412,899,900,248,807
G·ENERAL	924,927,855
G·OLDSTAR	776,530,797,798,803,818,830,861,862 901
G·RUNDIG	843,777,778,783,788,793,Video(874)
H·AIER	524,001,033,059,158,190,195,205 214,219,524,529,534,682,684,687 694,715,720,739,756,761,774,807 812,825,832
H·I-VISION	152
H·ITACHI	019,037,076,103,108,113,116,149,496 501,506,526,531,536,541,545,546,551 556,561,566,571,749,811,816,821,826 511,516,521
H·ORIZONT	530,901,902,903,775,789,794,796,799 801,823,837,857,859.

MARCA	CÓDIGO
H·ISENSE	133,003,016,022,024,034,035,043,044 132,163,168,173,185,204,209,229,276 281,291,296,301,338,343,348,448,453 458,463,511,516,519,535,538,548,553 558,559,563,564,567,568,569,572,573 574,578,579,582,583,584,587,589,592 602,607,612,622,627,632,642,647,672 677,699,700,704,705,706,710,711,716 766,779,856
H·YRUNDAI	746,133,447
J·AV	066
J·INXING (S·VA)	010,020,153,164,169,213,218,223,228 316,373,429,492,493,497,507,521,580 590,635,640,645,650,655,660,676,737 744
J·VC	757,762,767,772,802
K·ONKA	879,033,006,012,014,038,062,072,074 077,115,120,124,125,144,248,253,258 263,268,273,278,283,288,293,298,303 308,313,318,352,362,367,372,377,387 392,394,399,404,409,424,479,484,489 494,499,504,605,610,641,646,651,656 686,701,707,721,726,731,800,805,810 878
L·G	056,096,447,520,525,530,576, 586,591,596,601,771,776
L·OEWE	922
M·ITSUBISHI	760,829,831,834,835,860
N·EC	876
O·RION	904,905,923,807
P·ANAROMA	045
P·ANASONIC	906,053,078,114,133,243,319,324 329,334,339,344,349,354,359,364 434,439,444,550,696,817,822,864 869
P·ANDA	002,042,047,052,107,140,152,154 159,233,238,321,378,383,414,452 462,467,472,477,487,509,555,565 570,630,708.
P·EONY	017,082,135,189,310,488,512,517 522,665,666,671,691,742.
P·HILIPS	015,040,064,901,069,070,075,080 085,090,095,100,105,110,230,240 245,754,759,764
P·OLAR	020,447
P·ROWEST	926
P·RIMA	013,018,023,027,049,067,089,112,117 122,134,145,157,192,200,211,235,237 250,260,272,307,328,332,357,374,382 407,449,454,459,464,469,661,693,698 703,722.

MARCA	CÓDIGO
Q·INGHUATONGFANG	046,051,118,593,719,734,743
R·EKORD	133,907,908,909,910
R·OLSEN	176,432,157,883,775,789,794,796,799,801, 823,837,857,859,911,912
R·OWA	092,102,183,188,193,199,358,455,527, 581,690,695
R·UBIN	897,902,779,040
S·AMSUNG	877,007,009,137,142,147,194,306,360, 363,368,385,419,478,483,609,614,619, 624,629,634,670,675,680,681,685,755
S·ANAM	872,883
S·ANYO	011,058,101,123,143,148,206,333,503, 508,513,518,523,528,533,713,735,815, 820
S·ANSUI	748
S·HIVAKI	759,893,447,482

MARCA	CÓDIGO
S·KYWORTH	000,005,026,031,036,045,050,054,055, 060,065,079,086,091,111,121,129,138, 150,155,160,162,165,167,170,172,175, 177,180,182,187,197,202,207,212,217, 222,225,227,232,242,247,252,257,262, 267,277,282,287,292,297,302,312,317, 322,326,327,337,342,347,369,379,384, 389,470,490,515,532,539,540,544,549, 557,560,575,577,585,588,595,597,600, 603,608,613,617,618,623,628,633,637, 638,643,648,652,653,657,662,664,667, 669,673,674,678,702,709,712,717,725, 727,730,746,751,765,769,770,780,785, 790,839,844.
S·ITRONIKC	053
S·NOWA	875,880,882,928
S·OKOL	804,809
S·TRONG	833,842,847,851,866,868,
S·ONY	913,088,093,098,106,109,234,239,244, 249,254,259,264,269,274,279,284,289, 294,299,304,309,314,428,836
S·VA	025,041,198,203,208,554,738
S·HARP	917,104,126,388,393,398,403,408,413, 418,423,758,763,768,773
S·UPRA	746,794,133
T·CL	447,021,039,048,081,087,094,099,255, 265,270,275,280,290,295,300,305,320, 325,330,335,345,350,355,370,375,380, 395,397,400,402,405,410,412,417,420, 422,425,427,430,433,435,437,438,442, 443,445,450,460,465,475,480,485,495, 500,505,510,606,611,615,616,620,621, 625,626,631,636,639,644,649,654,659, 718,723,724,728,733,753,784,848.
T·HOMSON	853,914,915,916,792,824,828,838,867
T·OSHIBA	081,191,216,221,226,231,236,241,246, 251,256,261,266,286,311,336,356,391, 426,471,806
V·ESTEL	919,918,920,015
V·ITYAS	921,530,015
X·IHU	008,029,030,071,084,174,179,184,741
X.VISION	873
H·R13	882
O·THERS	004,032,057,073,083,097,119,127,128, 210,215,220,224,271,543,594,598,599, 604,689,692,697,714,732,736,747,750

INFORMACIÓN AMBIENTAL

Este producto puede contener sustancias que pueden ser dañinas para el entorno y para la salud humana si no es eliminado adecuadamente. Les entregamos por tanto la siguiente información para evitar el vertido de estas sustancias y para mejorar el uso de los recursos naturales. Los equipamientos eléctricos y electrónicos no deben ser eliminados a través de los normales desechos urbanos, tienen que ser enviados a una recogida selectiva para su correcto tratamiento. El símbolo del bidón tachado, colocado sobre el producto y en esta página, recuerda la necesidad de eliminar adecuadamente el producto al final de su vida. De esta manera es posible evitar que un trato no específico de las sustancias contenidas en estos productos, o un empleo inapropiado de los mismos pueda llevar a consecuencias dañinas para el entorno y para la salud humana. Se contribuye además a la recuperación, reciclaje y reutilización de muchos de los materiales contenidos en estos productos. Con tal objetivo los fabricantes y distribuidores de los equipamientos eléctricos y electrónicos organizan adecuados sistemas de recogida y desguace de estos productos. Al final de la vida del producto contacte con su distribuidor para obtener información acerca de las modalidades de recogida. Al comprar este producto Su distribuidor también le informará de la posibilidad de hacer gratis con otro dispositivo en la condición de fin de vida que sean de tipo equivalente y hayan realizado las mismas funciones que el producto adquirido, o si el tamaño no es más grande que 25 cm, AEE se puede hacer sin obligación de comprar el producto equivalente. La eliminación del producto de un modo diferente al descrito anteriormente, será punible de las sanciones previstas por la normativa nacional vigente en el país donde el producto sea eliminado. Les recomendamos también de adoptar otras medidas favorables al entorno: reciclar el embalaje interior y exterior con el cual el producto es suministrado y eliminar de manera adecuada las baterías usadas, (sólo si están contenidas en el producto) Con vuestra ayuda se puede reducir la cantidad de recursos naturales empleados en la fabricación de equipos eléctricos y electrónicos, minimizar el empleo de los vertederos para la eliminación de los productos y mejorar la calidad de la vida, evitando que sustancias potencialmente peligrosas sean vertidas en el entorno.

EC REP Furture Telecom Plus SL
Calle Purísima Concepción 7 1der,
28982 Parla, Madrid.
Info.futuretelecomplus@gmail.com

Fabricante: HK Uslink Trading Limited
Dirección: FLAT/RM A133 Blk 01 15/F Wah Sang Edificio Nos.14-18 Wong Chukyeung Calle Shatin
E-mail: services;@unicostar.com